



## SÉLECTION DU MANCHE DE RECHANGE ADÉQUAT LIMES DE MÉCANICIEN ET RÂPES

Forme	Code	4"	6"	8"	10"	12"
	1-100	5.2	06	09	09	13
	1-106			09	09	13
	1-110		06	09	09	13
	1-111		04			
	1-143		04	05	09	13
	1-210	5.2	06	09	09	13
	1-320			09	09	13
	6-342	5.2	06	09	09	13
	6-343			08	09	
	6-344			09	09	
	1-160	3.2	04	05	05	08
	1-170	3.2	04	05	05	
	1-230	3.2	04	05	05	08
	6-345			05	05	

■ Case jaune = manche  
9-484-XX-

■ Case bleue = manche  
9-485-XX-

■ Case orange =  
manche 9-486-XX

■ **Exemple** : Manche  
correspondant à la lime  
1-210-08-2-2 =  
**9-485-09-1P**

