















DETERMINE THE CORRECT SPARE HANDLE ENGINEERING FILES & RASPS

Shape	Code	4"	6"	8"	10"	12"
	1-100	5.2	06	09	09	13
	1-106			09	09	13
	1-110		06	09	09	13
	1-111		04			
	1-143		04	05	09	13
	1-210	5.2	06	09	09	13
	1-320			09	09	13
	6-342	5.2	06	09	09	13
	6-343			08	09	
	6-344			09	09	
	1-160	3.2	04	05	05	08
	1-170	3.2	04	05	05	
	1-230	3.2	04	05	05	08
	6-345			05	05	