

Video User manual

<https://youtu.be/7qrQU0eyXaM>



INDEX

- 1-BATTERY INSTALLATION (00:09 min)
- 2- ON/OFF (00:46 min)
- 3-UNITS SET (00:58 min)
- 4-TORQUE MODE (01:15 min)
- 5-ANGLE MODE (02:25 min)
- 6-TORQUE AND ANGLE CYCLE COUNTING (03:39 min)
- 7-BACKLIGHT ON/OFF (04:14 min)
- 8-KEYPAD LOCK & UNLOCK (04:29 min)
- 9-MAIN MENU: VIEWING STORED TORQUE AND ANGLE DATA (04:57 min)
- 10-MAIN MENU: DELETING STORED TORQUE AND ANGLE DATA (05:18 min)
- 11-VIEWING AND CLEARING WRENCH CYCLE COUNTER (05:40 min)
- 12-MAIN MENU: LANGUAGE (06:06 min)
- 13-ADDING A TORQUE PRESET (06:40 min)
- 14-ADDING AN ANGLE PRESET (07:13 min)
- 15-EDITING A PRESET (07:50 min)
- 16-DELETING A PRESET (08:18 min)
- 17-ADDING MULTIPLE PRESETS (08:35 min)
- 18-ADVANCED SETTINGS - SHOW INFO (09:47 min)
- 19-ADVANCED SETTINGS - SLEEP TIME (10:18 min)
- 20-ADVANCED SETTINGS - LCD CONTRAST (10:33 min)
- 21-ADVANCED SETTINGS - KEY BEEP (10:51 min)
- 22-ADVANCED SETTINGS - TARGET BEEP (11:06 min)
- 23-ADVANCED SETTINGS - AUTO BACKLIGHT (11:15 min)
- 24-ADVANCED SETTINGS - TOGGLE BACKLIFHT (11:24 min)
- 25-ADVANCED SETTINGS - VIBRATOR CONFIG (11:33 min)
- 26-ADVANCED SETTINGS - BATTERY TYPE (11:40 min)
- 27-ADVANCED CONFIGURATION - DATE AND TIME SET (11:56 min)
- 28-ADVANCED CONFIGURATION - CAL INTERVAL (12:35 min)
- 29-ADVANCED CONFIGURATION – DELETE ALL PRESETS (13:01 min)
- 30-ADVANCED CONFIGURATION -MODE SETUP - TORQUE THEN ANGLE (13:32 min)
- 31-ADVANCED CONFIGURATION –CALIBRATION MENU (14:33 min)